ELECAL



Application
LA1-D series auxiliary contact blocks are installed at the top of LA2-D control relay or LC1-D AC contactor for expanding the couples of auxiliary contacts points. Owing to adopting the contacting functions of sliding friction, the item can be self-cleaning & ensure the electric circuit to be reliable.

Specification

Model	LA1-D02	LA1-D04	LA1-D11	LA1-D13	LA1-D20	LA1-D22	LA1-D31	LA1-D40
Contact number	2NC	4NC	NO+NC	1NO+3NC	2NO	2NO+2NC	3NO+1NC	4NO



CJX2-D205NS